

Connections to Existing Loom/ Switches

Refer to Manual for further information

Connections to Sensors







(This is for logging use of the brake pedal. NOT Brake Fail / Handbrake input)
Join to +12v Brake Light Feed

Join to +12v Main Beam Feed

Join to +12v Rear Fog Light Feed

(CARE! - Do not confuse with Brake & Main Beam Input Wires)
Join to +12v Indicator Feeds

(Negative (-ve) Switched input)
Connect to Brake Fluid Reservoir Switch / Handbrake Switch



DIGIDASH-2 - PRO / SS
 WIRING SCHEMATIC